MAGNUMSTONE™ END CAP INSTALLATION INSTRUCTIONS

UNIQUELY DESIGNED TO PROVIDE AN EFFECTIVE RETAINING SOLUTION

128 021 | APRIL 2026 | VERSION 2

CIRTEX®
GAIN MORE GROUND™

TOOLS REQUIRED FOR INSTALLATION

- Hammer Drill with 12mm masonry drill bit.
- Impact driver with 18mm socket
- Marking / measuring equipment

MAGNUMSTONE END CAP BRACKET KIT COMPONENTS

- 12x75mm Screw Bolt x 4
- Bracket x2
- MagnumStone End Cap

HEIGHT	610mm
DEPTH	203mm
TOP WIDTH	51mm
BOTTOM WIDTH	102mm

INSTALLATION INSTRUCTIONS

Position the end cap against the block end, on prepared levelling pad, while taking care to ensure that the top & front edges align with the block.

Place the mounting bracket with the holes at 190mm centres facing downwards, flush with the block end edge, and mark the hole locations.

Avoid positioning bolt locations over recesses in the block surface to achieve maximum fastening penetration.

Drill 12mm holes to 80mm depth.

Tip: To reduce the risk of accidentally drilling through to the front face of the end cap, PVC adhesive can be used as a depth marker on the drill bit.

Confirm the end cap is correctly positioned against the block before driving the screw bolts in with the impact driver.

GAIN MORE GROUND

CIRTEX®

HEAD OFFICE 125 NGATI MARU HIGHWAY | THAMES 3578 | NZ
POSTAL ADDRESS PO BOX 470 | THAMES 3540 | NZ

0800 CIRTEX (247 839) | WWW.CIRTEX.CO.NZ

CIRTEX®
GAIN MORE GROUND™